

RPB® PAPR Instructions for 03-856 High Capacity Battery

EMPLOYERS: Read this manual, the RPB PAPR and the respirator head-top Instruction Manuals and carry out the Employer Responsibilities.



PRODUCT USERS: Read this manual, the RPB PAPR and the respirator head-top Instruction Manuals and follow the Product User Safety Instructions.

Manuals are regularly updated. Make sure this manual is available to all users for reference.

Current version of this manual and other languages:

rpbafety.com/industrial/resources

BATTERY PACK



WARNING

To reduce the risk of battery fire, explosion, fire, or electric shock with the charger, follow these precautions and procedures:

Before charging

- Allow the battery to cool before charging if it feels hot.
- Inspect the battery pack before every charge. If there are any cracks or damage do not charge the battery pack.
- Inspect the charger and power cords before use. Replace if any parts are damaged. Do not substitute, modify or add parts to the charger. Do not attempt to service the charger. There are no user-serviceable parts inside.
- Use only the provided charger and cord.

Where to charge

Charge only:

- indoors,
- in a dry area,
- away from sources of heat,
- away from anything that can burn if exposed to heat or flame,
- in a well-ventilated place,
- where the charger can be monitored and easily observed during charging.

Battery Charging

5 hours, 500+ cycles with battery life greater than 80% of original

Battery care

- Do not use the battery outside the recommended temperature limits -4° F to 140° F (-20° C to 60° C)
- Do not charge the battery outside the recommended temperature limits 32° F to 113° F (0° C to 45° C).
- Do not store the battery outside the recommended temperature limits of:
 - Less than 1 month: -4° F to 122° F (-20° C to 50° C) <90% RH
 - Less than 3 months: -4° F to 104° F (-20° C to 40° C) <85% RH
 - Less than 12 months: -4° F to 68° F (-20° C to 20° C) <85% RH

Do not disassemble or immerse the battery or charger in water or other liquids.

The battery can short if the contacts are accidentally connected by metal other than the RPB PAPR or the charger. To reset the battery, place the battery on the charging station. The battery will be ready to use again. While measures have been taken to protect the battery, damage can still occur, so be careful not to short any contacts together.

The battery has a shelf life of 1 year.

Long term storage

The battery has a shelf life of 6 months. Charge the battery until only 2 LEDs have been displayed on the charger for around 20 minutes before storing. Then place on the charger for 1½ hours every



Protecting you for life's best moments.

3 months. If battery pack has 3 green flashing lights on at start of charging, wait another 3 months before charging. Battery capacity can be checked by inserting it into a RPB PAPR and power it on, checking the battery meter on the side. Long term battery storage should be done at 40-60% capacity in a cool dry place. A battery stored at 100% charge and at higher storage temperatures, the more permanent capacity loss will occur. The battery pack may go into sleep mode if not used for 30+ days or drops to a low voltage. If this is the case, the battery pack may need resetting before use. If the battery gets below its minimum voltage it could result in an unrecoverable dead battery and could be dangerous to attempt charging.

Disposal

Dispose of battery packs according to local regulations. Do not crush, disassemble, dispose of in standard waste bins, in a fire, or send for incineration. Failure to properly dispose of battery packs may lead to environmental contamination, fire or explosion.

LIMITED WARRANTY

RPB® warrants that its Products will be free from defects in materials and workmanship for one (1) year, subject to the terms of this limited warranty. The Products are sold only for commercial use, and no consumer warranties apply to the Products. This limited warranty is for the benefit of the original Product purchaser, and cannot be transferred or assigned. This is the sole and exclusive warranty provided by RPB®, and ALL CONDITIONS AND IMPLIED WARRANTIES (INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE EXCLUDED AND DISCLAIMED FROM WARRANTY COVERAGE. RPB's® limited warranty coverage does not apply to damage resulting from accident, improper use or misuse of the Products, wear and tear resulting from the normal use of the Products, or the failure to properly maintain the Products.

RPB's® limited warranty coverage runs from the original date of purchase of the Products, and applies only to warranted defects which first manifest themselves and are reported to RPB® within the warranty period. RPB® retains the right to determine to its reasonable satisfaction whether any claimed defect is covered by this limited warranty.

If a warranted defect occurs, RPB® will repair or replace the defective Product (or a component of the Product), in its sole discretion. This "repair or replacement" remedy is the sole and exclusive remedy under this limited warranty, and under no circumstances shall RPB's® liability under this limited warranty exceed the original purchase price for the Products (or the applicable component). RPB® has no responsibility for incidental or consequential damages, including loss of use, maintenance and other costs, and ALL INCIDENTAL AND CONSEQUENTIAL DAMAGES ARE EXCLUDED AND DISCLAIMED from this limited warranty. Contact RPB® to obtain warranty service. Proof of purchase must be provided to obtain warranty service. All costs of returning the Products to RPB® for warranty service must be paid by the purchaser.

RPB® reserves the right to improve its Products through changes in design or materials without being obligated to purchasers of previously manufactured Products.

LIABILITY

RPB® Safety cannot accept any liability of whatsoever nature arising directly or indirectly from the use or misuse of RPB® Safety products, including purposes that the products are not designed for. RPB® Safety is not liable for damage, loss or expense resulting from the failure to give advice or information or the giving of incorrect advice or information, whether or not due to RPB® Safety's negligence or that of its employees, agents or subcontractors.

RPB® SAFETY - GLOBAL HEADQUARTERS

2807 Samoset Rd, Royal Oak, MI 48073, USA
T: 1-866-494-4599 F: 1-866-494-4509 E: sales@rpb-safety.com

RPB® SAFETY - APAC

3 Robin Mann Place, Christchurch Airport, Christchurch 8053, New Zealand
T: +64-3-357-1761 F: +64-3-357-1763 E: sales@rpb-safety.com

GVS S.p.A. - EMEA

Via Roma 50, 40069 Zona Industriale BO, Italy
T: +39 0516176391 E: sales@rpb-safety.com

GVS Filter Technology UK Ltd.

Vickers Industrial Estate, Mellishaw Ln, Morecambe LA3 3EN, UK
T: +44 (0)1524 847600 E: sales@rpb-safety.com

gvs-rpb.com

Form #: 7.20.578

Rev: 2